

MAX30100 Pulse Oximeter Interfacing with NodeMCU



❖ Max30100




- The MAX30100 Pulse Oximeter is a medical device that is used to measure blood oxygen saturation levels, heart rate, and pulse strength.
- It uses a non-invasive method to measure oxygen saturation levels in the blood.
- This module has a pair of LEDs (Light Emitting Diode) that emit a monochromatic red light at a wavelength of 660nm and infrared light at a wavelength of 940nm.
- As the photodiode emits light, it falls on the finger and gets absorbed by the oxygenated blood rest light is reflected through the finger and falls on the detector.
- The detector detects and processes the signals and gives the output.
- The MAX30100 sensor works on the I2C Serial Communication protocol.

❖ MAX30100 module Specification

- Operating voltage of the module is 1.7V to 3.3V.
- Supply current of 1200uA.
- The operating temperature range of the module is -40C to +85C.
- LED Current range 0mA to 50 mA.
- LED Pulse width range from 200us to 1.6ms

❖ MAX30100 Sensor Pinout



❖ MAX30100 Pin Description

- 1. VIN: Power supply pin connects in the range of
- 2. GND: Connect to Supply ground.
- 3. SCL: Serial Clock pin for I2C Serial Communication.
- 4. SDL: Serial Data pin for I2C Serial Communication.
- 5. INT: Active Low Interrupt pin.
- 6. IRD: IR LED Cathode and LED Driver Connection pin.
- 7. RD: Red LED Cathode and LED Driver Connection pin.

Connection

MAX30100 Sensor Pins	NodeMCU Pins
<u>SCL</u>	<u>D1</u>
<u>SDA</u>	<u>D2</u>
<u>INT</u>	<u>D0</u>
VCC	<u>3V</u>
<u>GND</u>	<u>GND</u>

❖ Installing Required Libraries

You have to open Library manager in Arduino IDE and search for max30100. Install the MAX30100lib by OXullo Intersecans as shown below.



❖Code

Available at this directory:


D:\nodeMcu\oximiter max30100 interface

Name :- oximiter_max30100_interface.ino

❖Testing



→ Run on given ip address in you mobile or laptop which network is same



Created By:
~AJAJ